













A	BLOW MOULDED TRAY		3 PCS
B	TUBULAR FRAME		2 PCS
C	CASTORS WITH BRAKE		2 PCS
D	CASTORS WITHOUT BRAKE		2 PCS
E	ANGLE BRACE		12 PCS
F	HEX BOLT		12 PCS
G	WASHER		12 PCS
H	NUT		12 PCS
I	RING SEATER		4 PCS
J	SCREW		4 PCS
K	SPRING WASHER		4 PCS
L	HEX WRENCH		1 PCS

**LUXOR | H. WILSON**

# **Assembly Instructions**

## **Model ATC332**

Customer Service Dept

2245 Delany Rd

Waukegan, IL 60087

Ph: 847-244-1800, 800-323-4656

Fax: 847-244-1818, 800-327-1698

### **Instructions:**

1. Take one of Tubular frame (B) and lay flat. Attach Blow molded tray (A) and Angle brace (E) to frame using Hex bolt (F), Washer (G) and Nut (H). (see image #1 on next page). \* Do not tighten the screws all the way down.
2. Assemble 2 other molded trays with tubular frame as step 1.
3. Assemble another side of tubular frame to blow molded trays. (as step 1 & 2).
4. To attach the caster, inserts Ring seater (I) over the stem in the caster, and using Screw (J) and Spring washer (K) fix with frame. Tighten casters with Hex wrench (L) that is provided (see image #2 on next page).
5. When unit is fully assembled, tighten screws all the way.