



Bolt-Down Kit

Installation Instructions



10ANCR

Bolt-Down Hardware:

- 1 3/8" Lag Shield
- 1 1-3/4" Lag Bolt
- 1 1" Diameter Washer

Tools Required:

- Power Drill (impact preferred) with 5/8" Carbide Bit
- Hammer
- Adjustable Wrench

www.smokersoutpost.com

© Copyright 2001. DCI Marketing, Inc. All rights reserved.

Step 1. Remove Smokers' Outpost™ lid.

Step 2. Position the bottom of Smokers' Outpost™ in the desired location.

Step 3. Drill one starter hole halfway between the center of the container and its outside edge. This hole should go through the plastic and start into the cement.

Step 4. Remove the container and finish drilling the hole to a depth of 1-3/4".

Step 5. Hammer lag shield into cement until flush with surface.

Step 6. Place waste container over hole and secure with lag bolt and washer.

Step 7. Replace Smokers' Outpost™ lid.

If you have any questions, please call DCI Marketing at 1-800-782-7273 • 1-414-228-7000 or Smokers' Outpost™ at 1-800-622-6069 • 1-850-650-6602.



Bolt-Down Kit

Installation Instructions



10ANCR

Bolt-Down Hardware:

- 1 3/8" Lag Shield
- 1 1-3/4" Lag Bolt
- 1 1" Diameter Washer

Tools Required:

- Power Drill (impact preferred) with 5/8" Carbide Bit
- Hammer
- Adjustable Wrench

www.smokersoutpost.com

© Copyright 2001. DCI Marketing, Inc. All rights reserved.

Step 1. Remove Smokers' Outpost™ lid.

Step 2. Position the bottom of Smokers' Outpost™ in the desired location.

Step 3. Drill one starter hole halfway between the center of the container and its outside edge. This hole should go through the plastic and start into the cement.

Step 4. Remove the container and finish drilling the hole to a depth of 1-3/4".

Step 5. Hammer lag shield into cement until flush with surface.

Step 6. Place waste container over hole and secure with lag bolt and washer.

Step 7. Replace Smokers' Outpost™ lid.

If you have any questions, please call DCI Marketing at 1-800-782-7273 • 1-414-228-7000 or Smokers' Outpost™ at 1-800-622-6069 • 1-850-650-6602.