

Instruction Sheet - LE Model Tables

Models LE-26 and LE-27 Two Shelf Mobile Tables

Models LE-34, LE-40, LE-42, LE-48 and LE-54 Three Shelf Mobile Tables



Customer Service Dept
2245 Delany Rd
Waukegan, IL 60087
Ph: 847/244-1800 • 800/323-4656
Fax: 847/244-1818 • 800/327-1698



LE - Two Shelf Model

LE - Three Shelf Model

PARTS LIST

Models LE26 & LE27

- 1 - Bottom shelf with casters sockets
- 1 - Top shelf with handle
- 4 - Long legs
- 4 - Casters (2 w/brake)
- 1 - Plug housing cover
- 2 - Sheet metal screws

Optional Electric Assembly:

- 1 - Electric cord
- 1 - Power cord retaining bracket
- 1 - Cord tie
- 3 - Sheet metal screws

Models LE34, LE40, LE42, LE48 & LE54


- 1 - Bottom shelf with casters sockets
- 1 - Top shelf with handle
- 1 - Center shelf with eight leg posts
- 4 - Short legs
- 4 - Long legs
- 4 - Casters (2 w/brake)
- 1 - Plug housing cover
- 2 - Sheet metal screws

Tools Required:


- 1 - Rubber Mallet
- 1 - Slotted Screwdriver

IMPORTANT:


If your LE table does not have the Optional Electrical Assembly start by closing the electric plug housing in the handle of the top shelf as illustrated. If your LE table has the Optional Electric Assembly, see assembly instructions below. Start by assembling electric.



PLUG HOUSING COVER




CORD RETAINING TRACK #2
CORD RETAINING TRACK #1
3-PLUG UNIT
POWER CORD PLUG RETAINING BRACKET



CORD MANAGEMENT TIE
TIE IS IN SECURED POSITION
POWER CORD MANAGEMENT TIES


- 1 Firmly seat electrical assembly 3 plug unit into handle plug housing as illustrated. Secure with power cord plug retaining bracket. Thread cord through cord retaining track and out the opening in the side of the handle.
- 2 Secure power cord management tie into starter hole with sheet metal screws. See illustration A. Secure with power cord management tie by wrapping tie around cord and fastening. Cut off any unnecessary extra length of tie.

- 3 Wrap the cord around the handle.




- 4 For safety and neat appearance secure cord plug to cord by utilizing plug snap.


Models LP-26 and LP-27




- 1 Lay top shelf (with handle) ribbed side up on a smooth surface. Push all 4 legs onto leg posts.



- 2 Position center shelf (with 8 leg posts) ribbed side up, over the 4 legs and insert leg posts into legs. Using a rubber mallet, firmly hammer center shelf into legs until all 4 legs are seated (flush) against the surfaces of both shelves.




- 2 Position bottom shelf, ribbed side up, over the 4 legs and insert leg posts into legs. Using a rubber mallet, firmly hammer bottom shelf into legs until all 4 legs are seated (flush) against the surfaces of both shelves.




- 3 Push remaining 4 legs into leg posts of center shelf.

FOR BIG WHEEL ASSEMBLY. See instructions in Big Wheel hardware pack.




- 3 Push the four casters firmly into the holes in each corner of the bottom shelf. Important: Casters must be fully seated. Tap firmly with rubber mallet to properly seat casters. Turn your LP table right side up. It is now ready for use.



- 4 Position bottom shelf, ribbed side up, over the 4 legs and insert leg posts into legs. Using a rubber mallet, firmly hammer bottom shelf into legs until all 4 legs are seated (flush) against the surfaces of both shelves.


Models LE-34, LE-40, LE-42, LE-48 and LE-54

*Models LE34 and LE40 use short legs first.
*Models LE42, LE48 and LE54 use long legs first.



- 1 Models LE-34 and LP-40: Lay top shelf (with handle) ribbed side up on a smooth surface. Push all 4 short legs onto leg posts. Models LE-42, LE-48 and LE-54: Lay top shelf (with handle) ribbed side up on a smooth surface. Push all 4 long legs onto leg posts.

FOR BIG WHEEL ASSEMBLY. See instructions in Big Wheel hardware pack.



- Push the four casters firmly into the holes in each corner of the bottom shelf. Important: Casters must be fully seated. Tap firmly with rubber mallet to properly seat casters. Turn your LE table right side up. It is now ready for use.

Instruction Sheet - Endura Mobile Cabinet Tables Instructions for LE-C Units with locking Cabinet
Models LE26C, LE27C

Customer Service Department
Luxor
2245 Delany Road
Waukegan, IL 60087
Ph: 847/244-1800 • 800/323-4656
Fax: 847/244-1818 • 800/327-1698



PARTS LIST


Models LE27C, LE26C

- | | |
|-----------------------------------|------------------------|
| 1 - Top shelf w/handle | 1 - Grommet Cap |
| 1 - Bottom shelf w/caster sockets | 1 - Cord guide cover |
| 4 - Legs | 2 - Grommet rings |
| 2 - Cabinet side panels | 1 - Rubber Band |
| 1 - Back Panel | 4 - Small 'U' brackets |
| 1 - Door in frame | 1 - Large 'U' bracket |
| 1 - Power cord | 1 - Cord wrap bracket |
| 4 - Casters 2 with brake | 2 - Stove bolts |
| 8 - 1 3/4" machine screws | |


Tools Required:

Rubber mallet


If you did not get an electric assembly with your cart start by closing the electric plug housing in the handle of the top shelf as illustrated below.




NOTE: Model LE-27C had double doors.




- 5
Install door panel same as back panel with door handle at top. Be sure door opens outward and door frame is also placed between legs and nested flush on the shelf floor.




- 1
With bottom shelf facing up push all four legs onto leg posts. Using rubber mallet hammer legs firmly into position. Legs must be seated (flush) against the shelf surface. Place rubber band around legs to aid in the assembly of cabinet side panels and doors.




- 2
Install the side panels first. Slide panels down between legs until they are nested inside the shelf lip and flush against the shelf surface. Rubber band will hold legs and side panels in place while installing back panel and front door.




- 3
Install the back panel in the same manner as side panels. Install grommet ring into grommet hole. Insert two stove bolts as illustrated through 'U' bracket into back panel and through slots in cord wrap bracket. Align the cord wrap bracket onto stove bolts from the outside of back panel, and secure with two keep nuts.




- 4
Press 3-outlet power cord into 'U' bracket and feed remaining cord through grommet hole and wrap remaining cord around cord wrap bracket. For safety and neat appearance, secure cord plug to cord with plug snap.



- 6
Begin seating of top shelf by holding door panel, leg and side panel as illustrated. Gently tap corner posts into legs until all posts are partially inserted into legs. Repeat hammering action more firmly going around to each corner, being certain that each panel nests inside the lip of the top shelf. Repeat this action until top shelf is fully nested.



- 7
Install grommet ring and grommet cap into top shelf. For tables with electric assembly, snap off cord guide cover from grommet cap to allow equipment plug entry. Insert grommet cap into grommet ring.



- 8
Push the four casters firmly into the holes in each corner of the bottom shelf. **Important:** casters must be fully seated. Tap firmly with rubber mallet to properly seat casters. Turn your Endura Table right side up.

Instruction Sheet - Endura Mobile Cabinet Tables
Models LE-34C, LE-40C, LE-42C, LE-48C and LE-54C



Customer Service Department
Luxor
2245 Delany Road
Waukegan, IL 60087
Ph: 847/244-1800 • 800/323-4656
Fax: 847/244-1818 • 800/327-1698



LE-54C



LE-40C



LE-42C









PARTS LIST

Models LE-34C, LE-40C, LE-42C, LE-48C, LE-54C

- | | |
|------------------------------------|----------------------|
| 1 - Top shelf w/handle | 1 - Door in frame |
| 1 - Center shelf w/eight leg posts | 1 - Grommet cap |
| 1 - bottom shelf w/caster sockets | 1 - Cord guide cover |
| 4 - Short legs | 1 - Grommet ring |
| 4 - Long legs | 1 - Rubber band |
| 2 - Cabinet side panels | |
| 1 - Back panel | |
| 4 - Casters 2 with brake | |

Tools Required:

Rubber mallet

1 IMPORTANT The electrical unit should be assembled first. If your Endura Cabinet Table does not have the Electrical Assembly and Cable-Track™ Cord Management System, start by closing the electrical plug housing in the handle of the top shelf as illustrated below.  Units with electric receive following parts: 1- Cord guide cover 1- Cord wrap 4- Cord ties 1- L-bracket 6- Screws 1- Power cord Units without electric receive following parts: 1- Cord guide cover 2- Screws 1- Plug housing cover	18" LEG  RUBBER BAND BOTTOM SHELF LEG POST 2 With bottom shelf facing up push all four 18" legs onto leg posts. Using rubber mallet hammer legs firmly into position. Legs must be seated (flush) against the shelf surface. Place rubber band around legs to aid in the assembly of cabinet side panels and doors.	TOP VIEW  SIDE PANEL LEGS SIDE VIEW WITH PANEL SEATED INSIDE SHELF LIP 3 Install the side panels first. Slide panels down between legs until they are nested inside the shelf lip and flush against the shelf surface. Rubber band will hold legs and side panels in place while installing back panel and front door. 6  CENTER SHELF 6 Begin seating of center shelf by holding door panel, leg and side panel as illustrated. Gently tap corner post into leg. Repeat on all 4 sides until all posts are partially inserted into legs. Now repeat hammering action more firmly going around to each shelf post and driving the leg posts more securely into the legs. Top of panels and door frame must be nested into the underside of the center shelf lip in the same manner as the bottom shelf.	 4 Install the back panel in the same manner as shown in Step #3. NOTE: Cabling hole in back panel should be toward the top. 7  CORD GUIDE COVER TOP SHELF CENTER SHELF GROMMET CAP GROMMET RING 7 Push remaining 4 legs onto center shelf posts as illustrated. Place top shelf (with handle) onto legs. Insert leg posts into legs of top shelf. Using rubber mallet, firmly hammer top shelf into legs until all four legs are seated against shelf surface. install grommet ring and grommet cap into top of shelf. For tables with electric assembly, snap off cord guide cover from grommet cap to allow equipment plug to be run through grommet. Insert grommet cap into grommet ring. Remove rubber band.	NOTE: Models LE-40C, LE-48C, and LE-54C have double doors.  5 Install door panel same as back panel, with door handle at top. 8  PLACE LOCKING CASTERS AS ILLUSTRATED BACK FRONT 8 Push the four casters firmly into the holes in each corner of the bottom shelf. Important: casters must be fully seated. Tap firmly with rubber mallet to properly seat casters. Turn your Endura Table right side up.
---	---	--	---	---

