

Crank Adjustable Dual Flat Panel TV Cart **Assembly Guide**

Table of Contents

| | |
|---|----|
| Table of Contents | 2 |
| Parts List & Hardware | 3 |
| <u>Assembly and Installation</u> | |
| Assembly of the right and left frame | 4 |
| Attach lower cross supports and crank rod | 5 |
| Attach mounting supports. | 6 |
| Attach flat panel mounting plates | 7 |
| Attach lower shelf to frame | 8 |
| Install the upper cross bar. | 9 |
| Flip the unit upright | 10 |
| Attach upper shelf to frame. | 11 |
| Install mounting hardware to displays. | 12 |
| Attach displays to unit. | 13 |
| Install the locking system | 14 |
| Unit complete | 15 |

Tools Recommended

- Phillips Screwdriver
- Soft Surface
- Marker



ATTENTION!

Do not fully tighten screws until completely assembled


A FLAT PANEL TV CART THAT FITS YOU

This unit was built with you in mind and every detail was carefully crafted. The following assembly guide is best accomplished with two people. If you have any questions or concerns give us a call at: **1-800-323-4656** or email at: **customerservice@luxorfurn.com**

Parts List





1 Assembly of the right and left frame




Gather Parts:
A , B , C , R , 8

2




Assistance Recommended




IMPORTANT: Using the crank handle for minor adjustments, align the crank adjustment rod so that it seats fully into both sides of frame.

Gather Parts:
K, J, P, 7

&




3 Attach mounting supports



Gather Parts:


T

&



15 x6
M8xAA


4 Attach flat panel mounting plates



Gather Parts:



N

&




5 x 8
M8x15

5 Attach lower shelf to frame



Gather Parts:
H


&




3 x 5
M6x40

6 Install the upper cross bar

1




2



Gather Parts:


G

&



2 x2
M6x48

7 Flip the unit upright




Gather Parts:
D




**Heavy Lifting:
Assistance
Required**

8 Attach upper shelf to frame

1




2




Gather Parts:
F

&



1 x4
M6x63



2 x1
M6x48

9 Install mounting hardware to displays

1


place allen wrench 7 into the hole and mark your bolt length.

Screen Size: 32"- 60"
Max. TV: 110 lbs.
Per Shelf: 33 lbs.*
Total Capacity: 209 lbs.*



*evenly distributed




Use proper screw 9-11 and washer 12-13 to avoid any damage to tv




2



10 x8
M5x16




11 x8
M6x16




12 x8
M6

Gather Parts:
L , M

&



9 x8
M8x35




13 x8
M8

10 Attach displays to unit




Make sure the crank adjustment is at the minimum required height so that the TV and shelf have proper spacing in between.




**Heavy Lifting:
Assistance
Required**

11 Install the locking system



Gather Parts:
Q , E , M1

12 Unit complete



Questions or Feedback Call Us at:

800-323-4656