

# NOTICE

We strive to constantly attain the highest degree of product quality possible. This is one reason why we can place a lifetime guarantee on every product we sell. Our manufacturing process for metal carts takes advantage of a special robotic arc-welding technique that insures your cart is perfectly square and your welds will remain rigid. Also, all our products are inspected for quality before shipment.

Occasionally tables are sprung from alignment. When this occurs your cart will appear to be welded incorrectly because the cart will not set square on the ground.

TRUCKERS CREATE THIS PROBLEM WHEN THEY DROP CARTONS ONTO ONE CORNER.

How to Correct the Problem:

In order to realign your cart, first remove all the casters and set the cart on a level concrete floor. Locate the corner which is lower than the others. Raise the cart from the floor and allow it to fall on that corner. Please note: It may be necessary to repeat this procedure two or three times. Your cart will then sit level. This process will neither damage nor lessen the integrity of your cart in any way. Please avoid using flat washers to level the cart. This reduces the length of the caster stem in the socket.

If you require further assistance, please contact your local dealer. Thank you.