



THERMAL FRESHTRAC™ (TFT) GUIDE AND CLEANING INSTRUCTIONS



TFT15G
1.5 Gallon Dispenser
With FreshTrac™ Lid

TFT1G
1.0 Gallon Dispenser
With FreshTrac™ Lid

TFT15G/TFT1G COMPONENTS



FRESHTRAC™ LID

STAINLESS STEEL TUBE

STEM



LIQUID LEVEL

Each bar represents the liquid level so you know how much coffee is in the dispenser at any time

COFFEE QUALITY TIMER

Counts down so you know when it is time to brew

ACTIVE LED LIGHTS

Green and red LED lights blink to indicate the freshness and volume of the coffee

The Liquid Level on the LCD screen will remain on (blink on and off) as long as there is liquid in the server, even if the quality timer has expired.

TFT15G/TFT1G LED LIGHT GUIDE

LIGHT COLOR	MEANING
Green/Red/Green	Activation/Reset.
Green	Time: Coffee is fresh. There are 11 or more minutes remaining on the Quality Timer. Volume: Dispenser contains more than 24 ounces of coffee.
Red	Time: The Quality Timer has expired. Volume: The dispenser is empty.
Green/Red	Time: The Quality Timer is almost expired. There are 10 or less minutes remaining. Volume: The dispenser is almost empty. There is approximately 12-24 ounces of coffee remaining.

TFT15G/TFT1G GUIDE TO LED AND LCD DISPLAY ACTIVITY*

Brewing coffee into an empty TFT Server

LED/LCD Display Activity:

- The LED lights will flash Green/Red/Green to indicate activation or reset.
- As the server fills with coffee:
 - The LED will flash Green/Red until the volume inside the server exceeds 24 ounces and then change to Green only, flashing every 6 seconds.
 - The number of Liquid Level Bars will increase as the server fills with coffee.
- The Quality Timer will reset and display the remaining time on LCD.



The coffee is fresh and the TFT Server contains more than 24 ounces of coffee

LED/LCD Display Activity:

- The Green LED Light will flash every 6 seconds.
- The Quality Timer will display the remaining time on the LCD.
- The volume of coffee in the server will be indicated by the number of Liquid Level Bars displayed on the LCD.



*Photos show example display information only.

The Quality Timer has expired

LED/LCD Display Activity:

- The Red LED Light will flash every 6 seconds for one hour.
- The LCD will flash on and off for one hour.
- The Quality Timer will display 0:00 to indicate that the timer has expired.
- The volume of coffee in the server will be indicated by the number of Liquid Level Bars displayed on the LCD.



The TFT Server is empty

LED/LCD Display Activity:

- The Red LED light will flash every 6 seconds for any time remaining on the Quality Timer and then for an additional hour.
- There will be no Liquid Level Bars displayed on the LCD, indicating that the server is empty.
- The LCD will flash for one hour after the Quality Timer has expired.



The Quality Timer has expired AND the TFT Server is empty

LED/LCD Display Activity:

- The Red LED light will flash every 6 seconds for one hour.
- The LCD will flash on and off for one hour.
- The Quality Timer will display 0:00 to indicate that the timer has expired.
- There will be no Liquid Level Bars displayed on the LCD, indicating that the server is empty.



The Quality Timer is ALMOST expired (10 minutes or less remaining)

LED/LCD Display Activity:

- The Green and Red LED lights will flash in a Green/Red sequence every 6 seconds.
- The remaining time left on the Quality Timer will continue to count down.
- The volume of coffee in the server will be indicated by the number of Liquid Level Bars displayed on the LCD.



The TFT Server is ALMOST empty (approximately 12-24 ounces remaining)

LED/LCD Display Activity:

- The Green and Red LED lights will flash in a Green/Red sequence every 6 seconds.
- There will be one Liquid Level Bar displayed on the LCD.
- If there is any time left on the Quality Timer, it will continue to count down.



The Quality Timer is **ALMOST** expired and the TFT Server is **ALMOST** empty

LED/LCD Display Activity:

- The Green and Red LED lights will flash in a Green/Red sequence every 6 seconds.
- The remaining time left on the Quality Timer will continue to count down.
- There will be one Liquid Level Bar displayed on the LCD.



As long as the TFT Server senses coffee inside the server, the LCD will stay on and the Liquid Level Bars will display on the screen.

WIPE THE TFT STEM CLEAN BEFORE EACH BREW CYCLE

Keeping the TFT stem free from coffee oil build-up ensures that accurate time and volume information is displayed.

TFT DISPENSER CLEANING

- 1 Completely empty dispenser before cleaning.
- 2 Place dispenser with brew-thru FreshTrac™ lid under the coffee brewer.
- 3 Remove the brew basket and place cleaning products in the center of the brew basket and replace (see product supplier information for number of cleaning tablets needed).
- 4 Press the brew button to brew hot water and the cleaning solution into the dispenser.
- 5 When the cycle is complete, leave the cleaning solution in the dispenser for approximately 15 minutes.
- 6 Use a cleaning brush to remove coffee oil build-up from inside the dispenser. Empty the dispenser.
- 7 Place under the brewer and run another brew cycle with water only to rinse the dispenser.
- 8 Empty the dispenser and run one more brew cycle with water only.
- 9 Rinse and empty. Dry thoroughly.

CLEANING TOOL



JB-1
(or other similar brush)

TFT COFFEE SERVER PRECAUTIONS

- Do not immerse coffee server in water.
- Do not place in dishwasher.
- Do not use harsh powders or cleaners containing chlorine.
- Do not use a wire brush or pot scour to clean inside liner.