


Wall Rack for Instability Balls

10-1740 5-ball rack

Secure wall mount bracket to wall using mounting hardware (not included). Hang 5-ball rack on wall mount bracket.


Remove 5-ball rack from wall mount bracket before inserting or removing instability balls from rack.



10-1744 10-ball rack

Secure 10-ball rack to wall using mounting hardware (not included). Rack should be secured through the 4 wall mount holes.


10-ball rack remains permanently mounted to wall. Insert and remove instability balls directly from wall mounted rack.



instability balls

Instability balls, MVP™ balance boards, and Multi-Axial Positioning Systems are sold separately.

Please contact your local supplier for more information.



related items

instability balls

- 10-1760 yellow level 1
- 10-1761 red level 2
- 10-1762 green level 3
- 10-1763 blue level 4
- 10-1764 black level 5

platforms

- 10-1776 16" / 41 cm diameter
- 10-1786 20" / 51 cm diameter
- 10-1796 30" / 76 cm diameter
- 10-1756 15x18" / 38x46 cm

Multi-Axial Platform System

- 10-1732 board only



Fabrication Enterprises
P.O. Box 1500
White Plains, NY 10602 (USA)
tel: 1-914-345-9300
fax: 1-914-345-9800
www.Fab-Ent.com



Authorized CE representative:
RMS UK Ltd.
28 Trinity Road
Nailsea, Somerset BS48 4NU (UK)