


TENA® Stretch Brief Sizing Instructions

To determine the accurate size, measure the individual's waist or hips (whichever is larger) and follow the chart below. The size of the brief is printed along the length of the wetness indicator.




| Sizes STRETCH ULTRA | Fits Waist/Hips |
|--|------------------------|
| Medium/Regular (lavender) Large/X-Large (beige) | 33" - 52" 41" - 64" |
| Now Available for the needs of larger/taller individuals | |
| 2XL (white) | 64" - 70" |
| 3XL (white) | 64" - 95" |
| STRETCH SUPER Medium/Regular (green) Large/X-Large (green) | 33" - 52" 41" - 64" |

You will generally find that women have larger hips while men have larger waists.

Questions? Contact us:

1.800.992.9939 | info.usa@tena.com | www.tena-usa.com













TENA® Stretch Brief Size-Wise Chart

Use this quick & easy reference guide to determine the appropriate TENA® Stretch Brief size.



Please note: this tool serves as a guideline only.



Traditional Brief Sizing

TENA® Stretch Ultra and Stretch Super Brief Sizing













