



FIRST CLASS™

FURNITURE POLISH

TM

DATA SHEET

PRODUCT DESCRIPTION:

First Class™ Furniture Polish is a premium silicone polish that cleans and waxes in one operation. Leaves a beautiful luster that resists dust, smudges and fingerprints. Ideal for veneer furniture, table tops, desks, chairs and more. May be used on vinyl, plastic and rubber surfaces. For use in schools, offices, department stores, hospitals, vehicles and nursing homes.

FEATURES:

Labor Saving:

Spray and wipe. No rubbing or need to change dust cloths. Makes waxing furniture as easy as dusting.

Efficient Cleaning:

Removes tough dirt and stains. Leaves a soil resistant barrier.

User Friendly:

Ready-to-use aerosol package simplifies application. Nothing to dilute.

PRODUCT SPECIFICATIONS:

pH	9.4 ± 0.3
Appearance	Milky White, Thick Liquid
Fragrance	Slight Solvent
Physical State	Liquid Under Pressure
Freezing Point	32°F
Solubility In Water	Dispersible
Warehouse Storage	(NFPA) Level 1 Aerosol
Flash Point	> 200°F

INGREDIENTS:

Water	7732-18-5
Mineral Spirits	64742-48-9
Isobutane	75-28-5
Propane	74-98-6
Polydimethylsiloxane	63148-62-9

DILUTIONS	HEALTH	FLAMMABILITY	REACTIVITY
CONCENTRATE	NFPA 1 HMIS	NFPA 1 HMIS	NFPA 0 HMIS
CONCENTRACION	SALUD	INFLAMABILIDAD	REACTIVIDAD

0	1	2	3	4
Minimal	Slight	Moderate	Serious	Severe
Mínimo	Mínimo	Moderar	Grave	Drástico

ECOLOGICAL INFORMATION:

- Recyclable Steel Can (Where Available)
- VOC Compliant
- Contains No CFC's

FIRST CLASS™ FURNITURE POLISH

DIRECTIONS

USE INFORMATION

Do not allow spray to fall on the floor or use on floors as surface will become very slippery.



BEDROOMS LIVING ROOMS LOBBIES

DIRECTIONS FOR USE:

1. **SHAKE** can well.
2. **SPRAY** surface while holding can upright 4" to 8" from the surface. To treat small areas or avoid falling mist spray directly on soft cloth.
3. **WIPE** dry with a clean soft cloth.

FIRST AID:

If in eyes or on skin, immediately flush with plenty of water. Get medical attention if irritation persists. **If inhaled**, remove to fresh air. Get medical attention. **If swallowed**, DO NOT induce vomiting. Get medical attention. NEVER GIVE ANYTHING BY MOUTH TO AN UNCONSCIOUS PERSON.

HANDLING AND STORAGE:

SUGGESTED STORAGE TEMPERATURE: Store inside at 40-90°F. **SPECIAL HANDLING AND STORAGE:** Handle in accordance with good industrial hygiene and safety practices. These practices include avoiding unnecessary exposure and removal of material from eyes, skin and clothing. Store in a cool, dry, ventilated area. Protect from freezing. **KEEP OUT OF REACH OF CHILDREN.**

PERSONAL PROTECTION:

Respiratory Protection: Not needed in normal use.
Ventilation: Use with adequate ventilation.
Eye Protection: Safety glasses are optional.
Protective Gloves: Protective gloves are optional.
Other Protective Clothing or Equipment: Wear clothing as necessary to prevent skin contact.

TRANSPORTATION INFORMATION:

U.S. DOT - Proper Shipping Name: Consumer Commodity, ORM-D
Marine Pollutant: No.

MSDS FAX RETRIEVAL
Read MSDS before using this product
800-551-0101
OBTENCIÓN DE HDSM POR FAX
Leer la HDSM antes de utilizar este producto

FOR CHEMICAL EMERGENCY
SPILL, LEAK, FIRE, EXPOSURE OR ACCIDENT
CALL CHEMTREC DAY OR NIGHT
800-424-9300
PARA EMERGENCIAS QUÍMICA DERRAMES,
ESCAPES, FUEGO, EXPOSICIÓN O ACCIDENTE
LLAMAR DE DÍA O DE NOCHE A CHEMTREC

TECH HOTLINE
800-810-4829
LINEA DE TÉCNICA