

PULLMAN-HOLT®

phc.com



HEPA Drum Vacuum

A drum vacuum gives you plenty of capacity for the big commercial, industrial jobs:

Wet: floods, spills slurry's, oils, asbestos etc.

Dry: Lead dust, silica, PCB's and other hazardous material

- Popular 2-hp, 2-stage long-life motor sits atop a steel drum to create the ultimate in vacuum recovery.
- Features an unsurpassed 55 gallons in wet recovery and 7.2 bushels of dry capacity.
- Offers superior vacuum recovery, ranging from dry, light particulates, to wet, heavy debris.
- Steel dolly features four each 3" non-locking casters.

Technical Specifications:

Model:	102ASB HEPA Drum Vac
Product Code:	B001136
Style:	wet/dry
Motor:	2HP, 2-stage
Water lift:	105"
CFM:	110
Recovery Dry:	7.2 bushels
Recovery Wet:	55 gallon
Shipping Weight:	124 lbs.

PULLMAN-HOLT

Big Red HEPA Drum Vacuum



Set-up:



1. Place adapter ring on any drum with 23" diameter



2. Insert wet pan with liquid shut-off float



3. Position steel spacer with clamps on top of wet pan



4. Insert HEPA filter inside of spacer with clamps



5. Position motorhead on top of filter and lock down with clamps

Tool Kit Includes:



B000311
10' hose
w/molded ends



B521007 - 5' 2-piece wand



B701563 - Floor Brush
aluminum 14"



B701564 - Squeegee
Floor Tool aluminum 14"



B701562 - Crevice Tool
aluminum 11"



B701612
Dust Brush
aluminum 3"

PULLMAN-HOLT®
phc.com