

PULLMAN-HOLT®

phc.com

Introducing the 45HEPA-TT with Tool Trigger

Pullman-Holt is pleased to announce a new HEPA vacuum, designed specifically to be used with power tools and dust management. The model 45HEPA-TT has a "Tool Trigger" feature allowing the operator to turn the vacuum on or off through the power tool. Stricter worker and environmental regulations are requiring tradesmen who cut and grind concrete and masonry materials to control dust. Collecting and containing dust increases worker and power tool productivity, extends life of the abrasives and reduces clean-up time and expense.

Features:

- **Commercial grade, long-life 2HP motor** - exceeds airflow and pick-up of vacuums purchased from home improvement stores.
- **Compact, low center of gravity design** - No tipping, easy handling, transporting and storage
- **Tested and certified HEPA filter** - Oversized HEPA filter with plenty of media to handle high airflow.
- **"Never Clog" Dacron filter bag** - Self-cleaning, maximizes airflow and prevents interruptions when picking up large volumes of dry, fine dust.
- **Positive locking, full swivel hoses** - No binding and flexible. Easy handling and storage.
- **50-foot power cord** - Operates in a wide area without changing electric outlets.



Technical Specifications:

Type:	Dry
HEPA Filter:	Individually tested and certified to have a minimum efficiency of 99.97% at .3 microns
Pre-filter:	"Never Clog" Dacron filter bag
Capacity:	10 gallon
CFM:	110
Waterlift:	105"
Power cord:	50 feet
Accessories:	10' x 1.50" crushproof hose (included) 4' x 1" power tool connection hose (included)
Product Code:	B100481
Weight:	33 lbs

Optional Tool Kit: (B100511)

B521007	5' two-piece steel wand
B527095	14" floor brush
B701615	crevice tool 17"
B000394	2" dust brush



PULLMAN-HOLT

Model 45HEPA-TT with Tool Trigger

Heavy-duty lift handle with cord hook

Safe and easy lifting and transport.

2HP commercial grade, two-stage motor

Fast and superior pick-up, both wet and dry.
Includes one year warranty – parts and labor.

Injection molded motorhead with low noise design

Allows for operation in sound sensitive areas.

Heavy duty steel clamps

durable lock-down of motorhead during vacuuming,
handling and transportation.

High efficiency, drop-in cloth filter bag

For maximum air flow without interruption.

**Positive locking, full swivel hose connection system
with button latch**

For easy handling and operation. Hose does
not bind.

50-foot power cord

Allows for use without extension cord.

Blow molded high-density polyethylene canister

Low center of gravity design prevents tipping, resists
impacts and provides superior air seal.

Heavy duty steel swivel casters

withstands constant handling and transportation re-
quired for professional jobsites.



PULLMAN-HOLT®
phc.com