



# Foam Filter Media

*Permanent Washable Filter Roll Media*

- 1/4", 1/2", 1" Thicknesses
- Washable for Repeated Use
- Withstands Wide Temperature Extremes

## Applications

Widely used as a permanent washable filter in place of metal filters or disposable panel filters in HVAC equipment, including:

- Room Airconditioners
- Fan Coil Units
- Unit Ventilators
- Air Handling Units
- Built Up Filter Banks

## Washable for Repeated Use

The media can be cleaned for re-use by vacuuming, flushing, washing in warm water and detergents, even steaming.

## Suitable for Difficult Operating Conditions

Foam media can withstand wide temperature extremes - from -50°F to +250°F. It can be sterilized in boiling water or steam. The chemical make up of foam media is not adversely affected by water, soap, detergents, oils, solvents or greases at normal temperatures.



*Airguard foam filter media is made with 30 pores per inch. It is available in pre-cut or bulk rolls.*

Performance Data	1/4"	1/2"	1"
Initial Resistance (In. W.G) @300 FPM	.05"	.12"	.16"
Arrestance	55%	60%	65%
Recommended Final Resistance (In. W.G)	.50"	.50"	.50"



ATI - Air Technology Industries  
 1612 N. Davis Av. • Ottawa, KS 66067  
 Customer Service Team: Phone: 1-800-624-8739 • Fax: 1-785-242-8700  
 Email: ati@ati-filters.com • www.ati-filters.com

[www.clcair.com](http://www.clcair.com)



ATI-FOAM-1008

Distributed by:

© 2008 CLARCOR Air Filtration Products.  
 CLARCOR Air Filtration Products has a policy of continuous product research and development and reserves the right to change design and specifications without notice.  
**Terms and Conditions of Sale can be accessed at [www.clcair.com](http://www.clcair.com)**