

Pedal with Ratcheting Strap

The CR900ENT Semi-Recumbent Bike features the innovative entertainment console so your users can watch, browse, and listen to any media they choose. Beyond the comfort molded seat and easy access, this bike is built to perform with durable components. Commercial crank assembly and extra-large roller bearings provide smooth pedal motion that can handle even the most rigorous workout. The robust drive train system is not only durable, but designed to stand the test of time.

## CR900ENT SEMI-RECUMBENT BIKE

- Extra wide, 8 groove poly-v belt, spring loaded idler for reduced belt tension for longer belt and bearing life
- Step-through design with easy infinite seat adjustments provides a comfortable workout
- Oversized 1" crank axle along with heavy duty roller bearings for reliable longevity
- Easy in and out ratcheting pedals with 2-degree pedal inversion for a comfortable workout
- 40 levels of resistance will keep you clients engaged during their entire workout



Integrated adjustable — fan for workout comfort

10.1" touchscreen display with multiple viewing modes

Tablet friendly reading rack holder

Accessory tray for secure placement of keys, smartphones, etc.





TV Watch your favorite TV shows right on the console, control the volume, and switch channels by tapping the virtual buttons on the cross



**DISPLAY** The system provides 3 different viewing modes (Simple, Track, Dashboard) to fine tune your workout experience.



INTERNET Easily access preselected websites and online apps such as YouTube, Facebook, and Twitter through the internet on the touchscreen.



SETTINGS The console is fully configurable with in-depth console settings. Easily set up the internet connections and modify what websites are available for the user. Also, customize the TV settings, perform diagnostics and maintenance, change default language, update software version, and more.

## CR900ENT SEMI-RECUMBENT BIKE

## **EQUIPMENT SPECIFICATIONS**

Console 10.1" touchscreen display, TV tuner with coaxial or HDMI input, wifi 802.11 b/g/n or ethernet,

3.5mm headphone jack, bluetooth 4.0, USB service port

**Programs** manual, hill, fat burn, cardio, strength, interval, fit test, HR, constant power, custom

Heart Rate contact and telemetric compatible (chest strap sold separately)

Resistance 40 levels

**Drive Train** extra wide, 8 groove poly-v belt with spring loaded idler

**Brake** EMS brake

**Flywheel System** 30 lbs. with 9.5:1 pedal to flywheel ratio **Pedals** ratcheting pedals with 2-degree inversion

**Frame** epoxy hybrid, double powder coated, heavy gauge high strength steel

**Dimensions**  $67'' \times 29'' \times 48''$ 

Product Weight 194 lbs.

Max User Weight 450 lbs.

## **WARRANTY INFORMATION**

Commercial (All Facilities) – Lifetime frame, 5 years EMS brake; 3 years parts and labor