

PULLMAN-HOLT®

phc.com



A drum vacuum gives you plenty of capacity for the big commercial, industrial jobs:

Wet: floods, spills, slurry's, oils etc.

Dry: dust, debris, construction materials, clean workbenches, machines, parts etc.

- Popular 2-hp, 2-stage long-life motor sits atop a steel drum to create the ultimate in vacuum recovery.
- Features an unsurpassed 55 gallons in wet recovery and 7.2 bushels of dry capacity.
- Offers superior vacuum recovery, ranging from dry, light particulates, to wet, heavy debris.
- Steel dolly features four each 3" non-locking casters.

Technical Specifications:

Model:	102 Drum Vac
Product Code:	B001135
Style:	wet/dry
Motor:	2HP, 2-stage
Recovery Dry:	7.2 bushels
Recovery Wet:	55 gallon
Water lift:	105"
CFM:	110
Shipping Weight:	108 lbs.

Wet Set-up:



1. Place adapter on drum



2. Insert wet pan with float shut-off for wet pickup



3. Position motorhead on top of filter

Dry Set-up:



1. Place adapter on drum



2. Insert modular filter frame



3. Position motorhead on top of filter

Tool Kit Includes:



B000311
10' hose
w/molded ends



B521007 - 5' 2-piece wand



B701563 - Floor Brush
aluminum 14"



B701564 - Squeegee
Floor Tool aluminum 14"



B701562 - Crevice Tool
aluminum 11"



B701612
Dust Brush
aluminum 3"