



## Metro Car Handle Plus – 6 Unit Counter Display Assembly Instructions

### **\*\*IMPORTANT NOTE\*\***

The square cut out on the front is for displaying a demo unit. From our research, when a customer can TOUCH and SEE the product quality, and become more familiar with the product and what it does, they are 3 times more likely to make the purchase.

#### **To assemble the display:**

1. Remove one of the units from its package, and insert the batteries (this will allow the customer to see the working flashlight)
2. **(Optional)** Take included zip tie and fish it down through the 2 small holes in the front of the display (see Figure A below)
3. **(Optional)** Now place Metro Car Handle Plus into the square cut out, wrap the zip tie around the handle, and tighten it to the display (see Figure B below)
  - a. **\*NOTE:** this step is optional because some retailers prefer to keep the unit loose so they can take customers out to their vehicle and show them how the product works
4. Now attach the included display header to the top of the display by staggering the 3 extruded pieces of card board; the middle extrusion to the back of the display, and the 2 end extrusions to the front. The finished display should look like the one in the image on the back in Figure C.

**Figure A**



**Figure B**





Figure C



[stander.com](http://stander.com)

Tel: 800.506.9901 • Fax: 435.787.2301 • 1615 Quail Way • Logan • UT 84321 • [sales@stander.com](mailto:sales@stander.com)